




retaining wall installation guide




1. Set pegs at each end of retaining wall site and connect string line to give you the required alignment. Holes should be dug at 2010mm centers




2. The post holes for the metre high wall must be dug to 1100mm deep. Once holes are completed place posts in the holes and add concrete. (Do Not over fill holes.) Concrete should not exceed 1010mm from the top of each post.



3. With the string line still in place check alignment of all posts with spirit level and recheck distances between posts. (I.e. 2010mm.) (A piece of wood or tube cut to this length will assist you to accurately check this dimension)



4. After concrete has cured in post holes overnight, place first sleeper between posts, then check measurement from the top of this sleeper to top of each post, (See 'A') you may need packing pieces under the bottom of this sleeper to get desired height. Once this height is correct add the remaining sleepers.



5. Once sleepers have been installed you will need to place plastic membrane behind the wall and Ag-pipe or strip drain at the bottom of the wall, cover pipe with 20mm gravel to allow for drainage.

* It is advisable to leave the footings to cure for 7 days prior to back filling